


How to Install a Car Stereo Steering Wheel Control Adapter

Many cars come with controls installed on their steering wheels to operate the car stereo. This allows the driver to drive safely without taking his hands off the wheel to operate the stereo. If you want to install an [aftermarket Android stereo](#) in your car, then it's necessary to adapt the wiring from the steering wheel to the stereo. This may require removing the lower dash panel underneath the steering wheel.



Things You'll Need

- Steering Wheel Control Adapter

Steps

1. Examine your vehicle manufacturer's instructions for the color of wire that you will be looking for on the stereo wiring harness. Remove any parts of the dashboard

that you need to and take out the stereo from the dashboard housing.

2. Locate the stereo harness. Follow manufacturer's instructions to connect the correct wires from the adapter to the corresponding wire on the [car stereo](#) wiring harness. This will differ model by model.
3. Plug the connector from the adapter wiring into the port on the back of the stereo, labeled "Steering wheel control".
4. Leave the stereo outside the dashboard. Turn on the ignition. An LED on the adapter should flash rapidly. Press the volume up button on the steering wheel until it stops flashing for two seconds. This will be followed by a series of flashes, culminating in the LED flashing nine times. The LED will then constantly be lit. Test the buttons with the stereo.
5. Reinsert the stereo into the dashboard housing. Reassemble the dashboard. Enjoy the added safety benefits of the steering wheel controls.

For more aftermarket Android stereo, please visit:


- US Site: <http://www.autopumpkin.com/>
- UK Site: <http://www.autopumpkin.co.uk/>
- DE Site: <http://www.autopumpkin.de/>

Source: ehow.com

[Pumpkin FAQ](#) **[What Should You Do if The Map Settings Can't](#)**

be Saved

Some guys might meet the map setting issues when using the [aftermarket Android 4.4 car stereo](#), such as the map color and speed alert setting can't be saved and need to reset every time when turning on the stereo. Here's the guidance to help you out:



1. Check if other settings such as radio, date and time can be saved or not. If all these settings can't be saved, then you might have plugged the Red ACC cable and Yellow memory wire (labeled with B+) into the wrong position. Thus, there is no memory and the Android 4.4 car stereo has no data to save. All you need to do is plugging them in the right position and the setting issue will be fixed.
2. If other settings can be saved, then there's something wrong with the map card or the map App. You may need a

new SD card and also a new map file (please contact sales@autopumpkin.com for it). After copying the map file into your empty new SD card, you need to insert it into the GPS slot. Then you can save the map setting without any issues.

For more Android car stereos, please visit:

- US Site: <http://www.autopumpkin.com/>
 - UK Site: <http://www.autopumpkin.co.uk/>
-